



Marketing Flash

4.3 Maintenance Release README

March 10, 2004

Known Issues with this Release

- Under CLI Port Location -> Add Subnets, the function does not check against the actual DHCP pools.
- CLI Failover Sibling status is case sensitive.
- Please note that the ISP Creation Page has been removed from the WMI and current.txt. The standard Portal Page redirect is to be used instead.
- The Subnet attribute in a RADIUS profile is not checked against the actual DHCP settings. Please make sure that the subnet VSA matches the configured DHCP pools.
- Static port mapping settings are not supported in the configuration synchronization functionality that is part of the fail-over option.
- The new Pop-Up Logout button will also display the logout option for pre-paid Credit Card users.
- The ICC does not display the buttons and the banners do not have a link on Windows Pocket PC.
- The ICC does not display buttons following a blank button entry.
- Changing the bandwidth in the ICC is not reflected in the Current Table.
- When IP Upsell is used in conjunction with the ICC, the bandwidth is always displayed as 1500:1500 regardless of the actual setting.
- WMI interface does not allow the setting of Double Quotes.
- The original Private IP address will be the IP address shown in subscribers' profiles even if they have changed to a public address.
- HotTelephone.com will not work with mis-configured subscribers.
- XML Add User command without entering a Password will insert '00' for that field.
- Using Mac OS X to telnet into the Nomadix gateway is not recommended.

- Importing Archive Configuration does not reboot the Nomadix gateway (except when using SNMP).
- “Remember Me” feature does not support Netscape running on Linux.
- The IP Upsell feature does not support Mac OS 8.5. For Linux system and Mac OS X, you need to reboot the system or release and renew the lease to get the new IP address.
- The “Store/Revenue Center Number: Other:” function in Micro PMS is not supported in this release.
- Some of the files on the Nomadix gateway flash directory may not reflect the actual modification and creation time and date. The incorrect time and date does not affect any Nomadix gateway function.
- Windows 95B does not support the Nomadix gateway’s IP Upsell feature.
- The subscriber experience for the error message “Too many subscribers are already logged in. Please try again later.” may differ dependent on the AAA settings of the device (on/off).
- The RADIUS Subnet VSA will appear in the RADIUS accounting packets even when the feature is disabled.
- Importing a location.txt with Subnets already setup will allow Port Location subnets that do not exist in the Nomadix gateway.
- Framed IP is 0.0.0.0 in the Accounting Start Message for Funk Odyssey Clients because the Odyssey Client sets the subscriber IP address to 0.0.0.0. Some RADIUS servers may not display 0.0.0.0 IP address.
- Upgrading from a firmware version that does not contain the Nomadix Multi-Subnet feature requires valid DHCP server settings. If not, the default DHCP server settings may need to be entered and dhcpgroups.txt and pools.txt will have to be deleted. After that the Nomadix gateway will need to be rebooted.
- Addresses can be added to the iNAT pool even if you do not have a valid license key. However, since the feature will not work without a license key, please make sure to obtain the right key prior to configuring this feature.
- SIM-based credit card (new Authorize.Net) and traditional credit card support functionality (ChainFusion, DataCenter) can be enabled simultaneously. However, they will not work at the same time.
- Importing archive.txt will not change the settings of the DHCP server.
- Network administrators are advised not to change plans from Normal to XoverY on-the-fly if they have users that have subscribed to the plans as this may lead to corruption of subscriber database since plans that no longer exist are referred by already existing users.

- If Micros Fidelio was selected before the upgrade then it will default to Pre-Paid Micros Fidelio Post Only after an upgrade. Similarly, if Lodging Link was selected before an upgrade, PMS disabled will be selected post upgrade.
- Clicking ADD on the Access Control Page enters and address of 0.0.0.0 to the access control list which would lock out all access to the system when enabled.
- When viewing SMTP relay settings in the CLI accepting the current settings will disable SMTP.
- Switching from no charge to charge port with RFC 1493 enabled, allows user to still have free access.
- The number of concurrent L2TP connections is limited to 30 concurrent L2TP tunnels.
- The settings for Secure XML are the same as the SSL settings under IWS configuration.
- For RADIUS auto-configuration, please make sure the current.txt is of the same version as the current firmware. There are known issues with using an older version of current.txt file.
- DHCP lease table states that all leases are available when they are not.

Implementation Recommendations

SSL Support

- It is recommended to use a non True Server Name for the SSL Common Name.
- SSL support has been extended to XML commands. Please note that SSL should be enabled if you wish to post XML commands over SSL.

DHCP

- For DHCP Relay—if the DHCP Server issues IP addresses that are on the same subnet as the Nomadix gateway, you must use the Nomadix gateway network IP as the DHCP agent IP.
- For DHCP Server—if you set up the DHCP Server on the Nomadix gateway that issues the IP address that is on the same subnet as the Nomadix gateway, you must have the DHCP server IP equal to the network side of the Nomadix gateway.
- Some DHCP servers may not support DHCP relay functions. For example, the Allied Telesis AR-320 Router does not support DHCP relay traffic from the Nomadix gateway, whereas all Cisco routers do.
- Existing IP Upsell settings may not work when upgrading the device to this release from releases before 4.2.

DNS

- Please note that DNS redirect ports have changed from ports 28 and 29 to ports 1028 and 1029 respectively.

Firmware Upgrade

- To upgrade the Nomadix gateway firmware to this version from any previous version, it is recommended to delete the curfile.dat, authfile.dat, and roomfile.dat files from flash. Please refer to the Firmware Upgrade Procedure document available from Nomadix Technical Support if you want to proceed with a firmware upgrade.
- Update your DHCP server setting if you disable the IP Upsell service. You can choose either DHCP relay or DHCP server, but not both.
- If you do not upload the new “factory.txt” file during the upgrade, when the upgrade is complete they must click the “Submit” button on all the submenus in the Subscriber Interface menu of the Web Management Interface. These include:
 - USG II->Subscriber Interface->Billing Options
 - USG II->Subscriber Interface->ICC Setup
 - USG II->Subscriber Interface->Language Support
 - USG II->Subscriber Interface->Login UI
 - USG II->Subscriber Interface->Subscriber Buttons
 - USG II->Subscriber Interface->Subscriber Labels
 - USG II->Subscriber Interface->Subscriber Errors, 1 of 2
 - USG II->Subscriber Interface->Subscriber Errors, 2 of 2
 - USG II->Subscriber Interface->Subscriber Messages, 1 of 3
 - USG II->Subscriber Interface->Subscriber Messages, 2 of 3
 - USG II->Subscriber Interface->Subscriber Messages, 3 of 3
- If you retain the current.txt file, you must reenter the ICC title page in the WMI.
- When using the In Room Port-Location Mapping feature with Tut System Espresso and Tut MDU Lite™, we recommend that you use IE4.0 or above.

History Log

- We do not Log FTP sessions in the history.

ICC

- It is not recommended to define a billing plan with ‘0’ as the bandwidth setting since the ICC will translate this to ‘unlimited’. The term ‘unlimited’ may cause some misunderstanding with certain customers since the Nomadix gateway may traffic shape the bandwidth to the maximum WAN speed.

Management Interface

- If the IP Upsell feature is enabled and the subscriber chooses a different IP address, the database will only track the IP address that is used for the initial login.
- System administrator username and password to the Nomadix gateway is limited to 11 characters.
- We recommend using the latest version of Internet Explorer when using the Web Management Interface.
- The default for Administrator Concurrency is off. If administrators want to turn it on, they can go to the Web Management Interface at System/Login.
- When Administrators logout from the Web Management Interface by clicking the Logout button, they must close all open browsers on their machine to complete the logout process. If they still have another open session of the browser, other people cannot login to the Nomadix gateway with different IP addresses. This issue only occurs when admin concurrency has been enabled.
- Concurrency from the same IP address: The Nomadix gateway does not support concurrency between multiple sessions in the WMI and with Telnet for managers/operators coming from the same IP address. This implies that if multiple users sitting behind a NAT device are trying to access the Nomadix gateway they

will all be able to access the Nomadix gateway simultaneously, since the source IP address is always that of the NAT device. Also, if a manager logs in to the Nomadix gateway via the WMI they can also login again via Telnet without having to logout from the WMI, and vice versa. The same is true for the operator.

- Multiple manager sessions on FTP are permitted.
- Both Administrators and Operators can ping from the Web Management Interface or Command Line Interface.
- History and System Uptime information are available from the Command Line Interface and the Web Management Interface, as well as SNMP.
- System administrators must enable “Passthrough” for using the portal page.

Proxy Support

- Please note that this release supports up to 4096 proxy sessions simultaneously.
- The transparent proxy feature supports HTTP and HTTPS traffic and the proxy ports have to be the same.

NetMeeting Support for Mis-configured Subscribers

- For mis-configured subscribers using NetMeeting, the meeting host needs to be on the network side of the Nomadix gateway.

PMS

- As defined in the PMS standards (Holodex, all HOBIC protocols and serial printer) systems support transactions in any currency but will only display “\$”.
- Please delete the Currfile.dat and Authfile.dat from the flash and if you change from the NH PMS setting to another PMS. Reboot the device.

PPTP

- We recommend that subscribers have the “Use default gateway on the remote network” option checked on their PPTP client software setup.

RADIUS

- For RADIUS subscriber setup, if there is no expiration time on the account, we recommend that system administrators set up a session time out on the user’s profile.
- You must turn on either NAS IP or NAS Identifier (or both) when setting up RADIUS.
- For RADIUS Proxy, it is recommended to only set the Nomadix gateway as the primary Authentication and Accounting server in the NAS. There is no need to set a secondary server.
- It is not recommended to set the retransmission time on the NAS to be less than the retransmission time on the Nomadix gateway.

SMTP

- When SMTP redirection for correctly configured subscribers is enabled, all traffic going to port 25 will be redirected.
- Depending on how the SMTP server was configured, the redirection may fail due to a change to the single IP address configuration. The relay server will have to be reconfigured to allow redirection from the network IP address of the NSE instead of the subscriber IP address.

Subscriber Configuration

- AOL users (with TCP/IP LAN setting) must first purchase Internet access using another browser (for example, Internet Explorer or Netscape) before they can use AOL.

- MacOS X has known issues on the network connectivity. Please check Apple.com for detail information.
- Subscribers must turn off the HTTP Mail Anti Virus on Gatelock X200 to allow Internet access.
- To allow MSN Explorer subscribers to access MSN Passport for authentication before purchasing Internet access through the Nomadix gateway, administrators must put login.pav0.hotmail.com and login.msna.passport.com in the DNS passthrough list.
- If you allow first time Netscape 6.0 users to create their local profile with Netscape before they have purchased the service, you can add “activation.netscape.com” and “ureg.netscape.com” to the DNS passthrough in the Web Management Interface.

VLAN Switch and Access Concentrator Port-Location Mapping

- Port-Location settings must not contain spaces, “=,” “&,” or “?” symbols, otherwise subscribers cannot access the External Web Server.

VPN Support

- This release supports Tunnel Mode using the Encapsulation Security Payload (ESP) protocol.

VoIP Device

- When using VoIP products on the network that does not allow subscriber to subscriber communication, you must add the VoIP product as a “device” through the Web Management Interface (WMI) and enable ‘Proxy ARP’.

Contact Information

Main:

Nomadix, Inc
 31355 Agoura Road
 Westlake Village, CA
 91361
 USA
 ++1.818.597.1500

<http://www.nomadix.com/>

Sales:

++1.818.597.1500

sales@nomadix.com

Technical Support:

++1.818.575.2590

support@nomadix.com