



Purpose: How to use the Terms of Agreement feature.

The Terms of Agreement page will be presented to the subscriber before the authentication process. The subscriber must agree to the terms in order to proceed with authentication.

Note: AAA must be enabled to use this feature.

Navigate to Subscriber Interface → Subscriber Messages, TOA

Enable Display of Terms of User Agreement Page and enter in your text in the text box. This is limited to 4000 characters and HTML characters can be used.

Click Submit to save.

Subscriber Page -- Terms of Agreement

Enable Display of Terms of User Agreement Page

Text for Terms of Agreement.

Total of 4000 characters max, including any HTML characters.

```
Nomadix.com. (hereinafter sometimes referred to  
as "Company"). <br><br>By accessing the Nomadix.com Website  
through this Hotel terminal and/or network station, you  
agree to pay Company the Equipment Usage Fee(s) according  
to the billing terms and further agree be bound by all the  
terms of this Agreement. <br><br><B>If you fail to meet the  
agreement you will be imprisoned for life..</B>
```

Revert

Revert all fields to default values

Submit

Reset



The user experience.



PARTIES TO THIS AGREEMENT The parties to this Agreement are you ("Customer") and Nomadix.com. (hereinafter sometimes referred to as "Company").

By accessing the Nomadix.com Website through this Hotel terminal and/or network station, you agree to pay Company the Equipment Usage Fee(s) according to the billing terms and further agree be bound by all the terms of this Agreement.

If you fail to meet the agreement you will be imprisoned for life..

Login

Once the subscriber clicks on Login, they will proceed with the authentication process enabled on the NSE.